

EverWoods Blinds



Luxaflex®

Welcome to the Luxaflex lifestyle

Thank you for purchasing Luxaflex®
EverWoods Blinds. With proper operation and
care your new blinds will provide years of
beauty and performance. Please review this
instruction booklet thoroughly for operation
and care information.

Operation

Manual Cord Lock operation

To tilt the slats:

Pull on one of the single cords to tilt the slats in one direction, and pull on the other cord to tilt the slats in the opposite direction.

To raise and lower the blinds:

Raise and lower the shade manually and lock in place with the cord lock. Wind excess cord around the cleats.

The cord lock has a locking device that holds the cords in place when they hang vertically down. To raise or lower the blind, pull the double cords towards the middle until you hear the cord lock disengage. When the blind is at the desired height, return the cord to the side of the blind to re-engage the cord lock.

IMPORTANT: When raising or lowering the blind, the slats should be in the open position.



LiteRise operation

To tilt the slats:

Simply rotate the wand to tilt the slats from fully closed to any desired angle.

To lower and raise the blind:

Simply push up using the bottom rail to raise the blind and pull down on the bottom rail to lower the blind.



Motorised operation

For motorisation information, please refer to SOMFY®, Merger® or PowerView® product brochure that is supplied with your blinds.



Care and cleaning

EverWoods Blinds combine the look of real wood with the quality and durability of advance technology that is resistant to discolouration and warping.

Routine maintenance

Dusting

Dust can be easily brushed off using a clean soft cloth, a feather duster or a vacuum cleaner with brush attachment.

To dust, tilt slats up and then down, to reach the top and bottom surfaces.

Spot cleaning

To remove stains, simply wipe with a sponge and lukewarm water.



The information and advice included in this brochure has been prepared with care. However, we are unable to accept responsibility for the results of or any damage caused during operation.

Luxaflex® EverWoods Blinds have been developed to capture the real look of wood and to eliminate any inconsistencies with colour, grain and pattern that might traditionally be found in real timber. However, small variations are considered normal, acceptable quality. Precautions should be taken to reduce exposure to harsh environmental elements, such as salt air, where regular cleaning maintenance is recommended.

Somfy is a registered trademark of Somfy SAS. © Copyright 2022 Hunter Douglas [ABN 98 009 675 709]. © Registered Trade Marks of Hunter Douglas. 18.017.030 C14375_08.2017